Lista de Compatibilidad 5015

		hone				
No	Brand	Model Name	V	Vindows XP	ws Vista	a / Windo
NO	Diana		Read	Wirte	Read	Wirte
		DV				
1	Sanyo	VPC-C4	Pass	Pass	-	-
2	Sony	DCR-SR200	Pass	Pass	Pass	Pass
3	Sony	DCR-SR300	Pass	Pass	Pass	Pass
4	Sony	DCR-SR62	Pass	Pass	Pass	Pass
5	Sony	DCR-SR82	Pass	Pass	Pass	Pass
6	Sony	HDR-CX7	Pass	Pass	Pass	Pass
7	Sony	HDR-CX7K	Pass	Pass	Pass	Pass
8	Sony	HDR-SR5	Pass	Pass	Pass	Pass
9	Sony	HDR-SR7	Pass	Pass	Pass	Pass
10	Sony	HDR-SR8	Pass	Pass	Pass	Pass
		DS	C			
11	AIPTEK	DV M2	Pass	Pass	Pass	Pass
12	Canon	A640	Pass	Pass	Pass	Pass
13	Canon	EOS 350D	Pass	Pass	-	-
14	Canon	IXUS 400	Pass	Pass	-	-
15	Canon	IXUS 500	Pass	Pass	Pass	Pass
16	Canon	IXUS 65	Pass	Pass	Pass	Pass
17	Canon	IXUS 860IS	Pass	Pass	Pass	Pass
18	Canon	PowerShot A640	Pass	Pass	-	-
19	Canon	PowerShot G5	Pass	Pass	Pass	Pass
20	Canon	PowerShot S30	Pass	Pass	-	-
21	Canon	PowerShot S3IS	Pass	Pass	-	-
22	Canon	PowerShot S400	Pass	Pass	-	-
23	Canon	Pro90IS	Pass	Pass	-	-
24	Casio	Exilim EX-Z40	Pass	Pass	-	-
25	Casio	Exilim EX-Z55	Pass	Pass	Pass	Pass
26	Casio	QV-R62	Pass	Pass	-	-
27	Fujifilm	FinePix A310	Pass	Pass	-	-
28	Fujifilm	FinePix S5000	Pass	Pass	-	-
29	Fujifilm	FinePix S602	Pass	Pass	-	-
30	Fujifilm	FinePix S9500	Pass	Pass	Pass	Pass
31	Kodak	CX6330	Pass	Pass	-	-
32	Minolta	DiMAGE F200	Pass	Pass	Pass	Pass
33	Minolta	DIMAGE Xt	Pass	Pass	-	-
34	Nikon	Coolpix 3100	Pass	Pass	-	-
35	Nikon	Coolpix 3200	Pass	Pass	-	-
36	Nikon	Coolpix 5900	Pass	Pass	-	-
37	Nikon	D100	Pass	Pass	-	-
38	Nikon	D40	Pass	Pass	_	-
39	Olympus	C-2	Pass	Pass	-	-
40	Olympus	C-720	Pass	Pass	_	_
41	Olympus	C-740	Pass	Pass	-	-
42	Olympus	u1000	Pass	Pass	-	_
	Olympus	µ300	Pass	Pass	_	-

44	Olympus	μ410	Pass	Pass	-	-
45	Panasonic	DMC FX1	Pass	Pass	Pass	Pass
46	Panasonic	LUMIX F7 (DMC-F7)	Pass	Pass	-	-
47	Panasonic	LUMIX FX7 (DMC-FX07GT)	Pass	Pass	-	-
48	Panasonic	LUMIX FX9 (DMC-FX9)	Pass	Pass		-
49	Panasonic	LUMIX FZ20 (DMC-FZ20)	Pass	Pass	-	-
50	Panasonic	LUMIX LC33	Pass	Pass	-	-
51	Panasonic	LUMIX LX2	Pass	Pass	-	-
52	Pentax	OPTIO M10	Pass	Pass	-	-
53	Richo	Caplio-R4	Pass	Pass	-	_
54	Sony	DSC-H3	Pass	Pass	Pass	Pass
55	Sony	DSC-H5	Pass	Pass	Pass	Pass
56	Sony	DSC-H9	Pass	Pass	Pass	Pass
57	Sony	DSC-P10	Pass	Pass	Pass	Pass
58	Sony	DSC-P200	Pass	Pass	Pass	Pass
59	Sony	DSC-T1	Pass	Pass	Pass	Pass
60	Sony	DSC-T2	Pass	Pass	Pass	Pass
61	Sony	DSC-T200	Pass	Pass	Pass	Pass
62	Sony	DSC-T70	Pass	Pass	Pass	Pass
63	Sony	DSC-T9	Pass	Pass	Pass	Pass
64	Sony	DSC-W1	Pass	Pass	Pass	Pass
65	Sony	DSC-W200	Pass	Pass	Pass	Pass
66	Sony	DSC-W80	Pass	Pass	Pass	Pass
67	Sony	DSLR-A200	Pass	Pass	Pass	Pass
68	Sony	DSLR-A700	Pass	Pass	Pass	Pass
69	Sony	NSC-GC1	Pass	Pass	Pass	Pass
		Cell Phone				
70	Nokia	6233	Pass	Pass	Pass	Pass

- : Not Tested (Only a certain function of this device was tested) NS: This function is not supported.

Remark:

1. ** Devices compatibility should be the same on both Windows VISTA and Windows 7, except for the case that the device does NOT support the OS.

No	Brand	Model Name	W	indows XP	ws VIST	A/ Widno	Remark		
NO	Dianu	Model Name	Read	Wirte	Read	Wirte	Wirte		
Hard Disk									
1	Airlink	USB Enclosure (AEN-U55)	Pass	Pass	-	-			
2	Benq	EW1621	Pass	Pass	-	-			
3	Buffalo	HD-PH80U2/UC-BK	Pass	Pass	Pass	Pass			
4	Corega	CG-U2HDC25	Pass	Pass	-	-			
5	Cypress	Cypress Semiconductor USB2.0 Storage	Pass	Pass	Pass	Pass			
6	Edge	EDGDC-196318-PE DiskGO 20GB USB HDD	Pass	Pass	Pass	Pass			
7	Genuine	Scopio	Pass	Pass	-	-			

8 Hitlachi	tachi 2.5"	Hit	2.5" USB HDD	Pass	Pa	ass Pass	Pass	
10 O Data								
11 OGear								
12							Pass	
13								
14 Logitec								
15 Logitec								
16 Logitec								
17 Logitec								
18 Logitec								
19 Logliec								
Description								
1 1 1 1 1 1 1 1 1 1								
22 Logitec								
23 Logitec LHD-ED400FU2 Pass Pass Pass Pass 24 Logitec LHD-ED400SAU2 Pass Pass Pass Pass 25 Logitec LHD-ED400U2 Pass Pass Pass Pass 26 Logitec LHD-ED500FU2 Pass								
24 Logitec LHD-ED400FU2 Pass Pass Pass Pass 25 Logitec LHD-ED400U2 Pass Pass Pass Pass 26 Logitec LHD-ED500FU2 Pass Pass Pass Pass 27 Logitec LHD-ED500FU2 Pass Pass Pass Pass 28 Logitec LHD-ED500SAU2 Pass Pass Pass Pass 29 Logitec LHD-ED640FU2 Pass Pass Pass Pass 30 Logitec LHD-ED640FU2 Pass Pass Pass Pass 31 Logitec LHD-ED640U2 Pass Pass Pass Pass 32 Logitec LHD-ED750FU2 Pass Pass Pass Pass 33 Logitec LHD-ED750FU2 Pass Pass Pass Pass 34 Logitec LHD-B250FU2 Pass Pass Pass Pass 35 Log								
25 Logitec LHD-ED400XAU2 Pass Pass Pass Pass 26 Logitec LHD-ED400U2 Pass Pass Pass Pass 27 Logitec LHD-ED500FU2 Pass Pass Pass Pass 28 Logitec LHD-ED500XAU2 Pass Pass Pass Pass 29 Logitec LHD-ED640FU2 Pass Pass Pass Pass 30 Logitec LHD-ED640SAU2 Pass Pass Pass Pass 31 Logitec LHD-ED640W2 Pass Pass Pass Pass Pass 32 Logitec LHD-ED750FU2 Pass								
26 Logitec LHD-ED400U2 Pass								
Pass								
28 Lögitec LHD-ED500SAU2 Pass Pass Pass Pass 29 Logitec LHD-ED500U2 Pass Pass Pass Pass 30 Logitec LHD-ED640FU2 Pass Pass Pass Pass 31 Logitec LHD-ED640U2 Pass Pass Pass Pass 32 Logitec LHD-ED750FU2 Pass Pass Pass Pass 33 Logitec LHD-ED750FU2 Pass Pass Pass Pass 34 Logitec LHD-ED750FU2 Pass Pass Pass Pass 35 Logitec LHD-ED750FU2 Pass Pass Pass Pass 36 Logitec LHD-HB250FU2 Pass Pass Pass Pass 37 Logitec LHD-HB250FU2 Pass Pass Pass Pass 38 Logitec LHD-HB300FU2 Pass Pass Pass Pass 40 Lo								
29 Logitec LHD-ED640FU2 Pass Pass Pass Pass 30 Logitec LHD-ED640FU2 Pass Pass Pass Pass 31 Logitec LHD-ED640U2 Pass Pass Pass Pass 32 Logitec LHD-ED750FU2 Pass Pass Pass Pass 33 Logitec LHD-ED750SAU2 Pass								
30 Logitec LHD-ED640FAU2 Pass Pass Pass Pass 31 Logitec LHD-ED640SAU2 Pass Pass Pass Pass 32 Logitec LHD-ED750FU2 Pass Pass Pass Pass 33 Logitec LHD-ED750FU2 Pass Pass Pass Pass 34 Logitec LHD-ED750U2 Pass Pass Pass Pass 35 Logitec LHD-ED750U2 Pass Pass Pass Pass Pass 36 Logitec LHD-HB250FU2 Pass Pass Pass Pass 37 Logitec LHD-HB300FU2 Pass Pass Pass Pass 38 Logitec LHD-HB300FU2 Pass Pass Pass Pass 40 Logitec LHD-HB320FU2 Pass Pass Pass Pass 41 Logitec LHD-HB300FU2 Pass Pass Pass Pass <td< td=""><td></td><th></th><td></td><td></td><td></td><td></td><td></td><td></td></td<>								
31 Logitec LHD-ED640V2 Pass Pass Pass Pass 32 Logitec LHD-ED750FU2 Pass Pass Pass Pass 34 Logitec LHD-ED750SAU2 Pass Pass Pass Pass 35 Logitec LHD-ED750U2 Pass Pass Pass Pass 36 Logitec LHD-HB250FU2 Pass Pass Pass Pass 37 Logitec LHD-HB250FU2 Pass Pass Pass Pass Pass 38 Logitec LHD-HB300FU2 Pass Pass <td< td=""><td></td><th></th><td></td><td></td><td></td><td></td><td></td><td></td></td<>								
32 Logitec LHD-ED640U2 Pass Pass Pass Pass 33 Logitec LHD-ED750FU2 Pass Pass Pass Pass 34 Logitec LHD-ED750AU2 Pass Pass Pass Pass 35 Logitec LHD-ED750U2 Pass Pass Pass Pass 36 Logitec LHD-HB250FU2 Pass Pass Pass Pass 37 Logitec LHD-HB350FU2 Pass Pass Pass Pass 38 Logitec LHD-HB300FU2 Pass Pass Pass Pass 39 Logitec LHD-HB300U2 Pass Pass Pass Pass 40 Logitec LHD-HB320U2 Pass Pass Pass Pass 41 Logitec LHD-HB300U2 Pass Pass Pass Pass 42 Logitec LHD-HB400FU2 Pass Pass Pass Pass 43 Logite								
33 Logitec LHD-ED750FU2 Pass Pass Pass Pass 34 Logitec LHD-ED750SAU2 Pass Pass Pass Pass 35 Logitec LHD-ED750U2 Pass Pass Pass Pass 36 Logitec LHD-HB250FU2 Pass Pass Pass Pass 37 Logitec LHD-HB300FU2 Pass Pass Pass Pass 38 Logitec LHD-HB300FU2 Pass Pass Pass Pass 39 Logitec LHD-HB300U2 Pass Pass Pass Pass 40 Logitec LHD-HB30U2 Pass Pass Pass Pass 41 Logitec LHD-HB400FU2 Pass Pass Pass Pass 42 Logitec LHD-HB400U2 Pass Pass Pass Pass 43 Logitec LHD-HB500FU2 Pass Pass Pass Pass 45 Logit								
34 Logitec LHD-ED750SAU2 Pass Pass Pass Pass 35 Logitec LHD-ED750U2 Pass Pass Pass Pass 36 Logitec LHD-HB250FU2 Pass Pass Pass Pass 37 Logitec LHD-HB250U2 Pass Pass Pass Pass 38 Logitec LHD-HB300FU2 Pass Pass Pass Pass 39 Logitec LHD-HB300FU2 Pass Pass Pass Pass 40 Logitec LHD-HB320FU2 Pass Pass Pass Pass 41 Logitec LHD-HB320FU2 Pass Pass Pass Pass 42 Logitec LHD-HB320FU2 Pass Pass Pass Pass 42 Logitec LHD-HB400FU2 Pass Pass Pass Pass 43 Logitec LHD-HB500FU2 Pass Pass Pass Pass 45 Lo								
35 Logitec LHD-ED750U2 Pass Pass Pass Pass 36 Logitec LHD-HB250FU2 Pass Pass Pass 37 Logitec LHD-HB30DC2 Pass Pass Pass 38 Logitec LHD-HB300FU2 Pass Pass Pass 39 Logitec LHD-HB320FU2 Pass Pass Pass 40 Logitec LHD-HB320FU2 Pass Pass Pass 41 Logitec LHD-HB320U2 Pass Pass Pass 41 Logitec LHD-HB400FU2 Pass Pass Pass 42 Logitec LHD-HB400FU2 Pass Pass Pass 43 Logitec LHD-HB400FU2 Pass Pass Pass 44 Logitec LHD-HB500FU2 Pass Pass Pass 45 Logitec LHD-HB570FU2 Pass Pass Pass 46 Logitec LHD-HB750U2 Pass								
36 Logitec LHD-HB250FU2 Pass Pass Pass Pass 37 Logitec LHD-HB300FU2 Pass Pass Pass Pass 38 Logitec LHD-HB300U2 Pass Pass Pass Pass 40 Logitec LHD-HB320U2 Pass Pass Pass Pass 41 Logitec LHD-HB320U2 Pass Pass Pass Pass 42 Logitec LHD-HB320U2 Pass Pass Pass Pass 42 Logitec LHD-HB400FU2 Pass Pass Pass Pass 43 Logitec LHD-HB500FU2 Pass Pass Pass Pass 44 Logitec LHD-HB500FU2 Pass Pass Pass Pass 45 Logitec LHD-HB750FU2 Pass Pass Pass Pass 46 Logitec LHD-HB750U2 Pass Pass Pass Pass 48 Logite								
37 Logitec LHD-HB250U2 Pass Pass Pass Pass 38 Logitec LHD-HB300FU2 Pass Pass Pass Pass 39 Logitec LHD-HB30U2 Pass Pass Pass Pass 40 Logitec LHD-HB320FU2 Pass Pass Pass Pass 41 Logitec LHD-HB320FU2 Pass								
38 Logitec LHD-HB300FU2 Pass Pass Pass Pass 39 Logitec LHD-HB300U2 Pass Pass Pass Pass 40 Logitec LHD-HB320FU2 Pass Pass Pass Pass 41 Logitec LHD-HB320U2 Pass Pass Pass Pass 42 Logitec LHD-HB400FU2 Pass Pass Pass Pass 43 Logitec LHD-HB400U2 Pass Pass Pass Pass 44 Logitec LHD-HB500FU2 Pass Pass Pass Pass 45 Logitec LHD-HB500U2 Pass Pass Pass Pass 46 Logitec LHD-HB576FU2 Pass Pass Pass Pass 47 Logitec LHD-HBS1000U2 Pass Pass Pass Pass 48 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Log								
39 Logitec LHD-HB300U2 Pass Pass Pass Pass 40 Logitec LHD-HB320FU2 Pass Pass Pass Pass 41 Logitec LHD-HB320U2 Pass Pass Pass Pass 42 Logitec LHD-HB400FU2 Pass Pass Pass Pass 43 Logitec LHD-HB500FU2 Pass Pass Pass Pass 44 Logitec LHD-HB500FU2 Pass Pass Pass Pass 45 Logitec LHD-HB570FU2 Pass Pass Pass Pass 46 Logitec LHD-HB750FU2 Pass Pass Pass Pass 47 Logitec LHD-HB750U2 Pass Pass Pass Pass 48 Logitec LHD-HBS1000U2 Pass Pass Pass Pass 49 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Lo								
40 Logitec LHD-HB320FU2 Pass Pass Pass Pass 41 Logitec LHD-HB320U2 Pass Pass Pass Pass 42 Logitec LHD-HB400FU2 Pass Pass Pass Pass 43 Logitec LHD-HB400U2 Pass Pass Pass Pass 44 Logitec LHD-HB500FU2 Pass Pass Pass Pass 45 Logitec LHD-HB750U2 Pass Pass Pass Pass 46 Logitec LHD-HB750U2 Pass Pass Pass Pass 47 Logitec LHD-HB750U2 Pass Pass Pass Pass 48 Logitec LHD-HBS1000U2 Pass Pass Pass Pass 49 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Logitec LHD-HBS250AU2 Pass Pass Pass Pass 51 Log								
41 Logitec LHD-HB320U2 Pass Pass Pass Pass 42 Logitec LHD-HB400FU2 Pass Pass Pass Pass 43 Logitec LHD-HB400U2 Pass Pass Pass Pass 44 Logitec LHD-HB500FU2 Pass Pass Pass Pass 45 Logitec LHD-HB500U2 Pass Pass Pass Pass 46 Logitec LHD-HB750FU2 Pass Pass Pass Pass 47 Logitec LHD-HB750U2 Pass Pass Pass Pass 48 Logitec LHD-HBS1000U2 Pass Pass Pass Pass 49 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Logitec LHD-HBS250AU2 Pass Pass Pass Pass 51 Logitec LHD-HBS300FU2 Pass Pass Pass Pass 52 L			LHD-HB320FU2	Pass	Pa	ass Pass	Pass	
42 Logitec LHD-HB400FU2 Pass Pass Pass Pass 43 Logitec LHD-HB400U2 Pass Pass Pass Pass 44 Logitec LHD-HB500FU2 Pass Pass Pass Pass 45 Logitec LHD-HB500U2 Pass Pass Pass Pass 46 Logitec LHD-HB750FU2 Pass Pass Pass Pass 47 Logitec LHD-HB750U2 Pass Pass Pass Pass Pass 48 Logitec LHD-HBS1000U2 Pass	U							
43 Logitec LHD-HB400U2 Pass Pass Pass Pass 44 Logitec LHD-HB500FU2 Pass Pass Pass Pass 45 Logitec LHD-HB500U2 Pass Pass Pass Pass 46 Logitec LHD-HB750FU2 Pass Pass Pass Pass 47 Logitec LHD-HB8700U2 Pass Pass Pass Pass 48 Logitec LHD-HBS1000U2 Pass Pass Pass Pass 49 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Logitec LHD-HBS250SAU2 Pass Pass Pass Pass 51 Logitec LHD-HBS250U2 Pass Pass Pass Pass 52 Logitec LHD-HBS300FU2 Pass Pass Pass Pass 53 Logitec LHD-HBS300SAU2 Pass Pass Pass Pass			LHD-HB400FU2	Pass	Pa	ass Pass	Pass	
44 Logitec LHD-HB500FU2 Pass Pass Pass Pass 45 Logitec LHD-HB500U2 Pass Pass Pass Pass 46 Logitec LHD-HB750FU2 Pass Pass Pass Pass 47 Logitec LHD-HB750U2 Pass Pass Pass Pass 48 Logitec LHD-HBS1000U2 Pass Pass Pass Pass 49 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Logitec LHD-HBS250SAU2 Pass Pass Pass Pass 51 Logitec LHD-HBS250U2 Pass Pass Pass Pass 52 Logitec LHD-HBS300FU2 Pass Pass Pass Pass 53 Logitec LHD-HBS300SAU2 Pass Pass Pass Pass								
45 Logitec LHD-HB500U2 Pass Pass Pass Pass 46 Logitec LHD-HB750FU2 Pass Pass Pass Pass 47 Logitec LHD-HB750U2 Pass Pass Pass Pass 48 Logitec LHD-HBS1000U2 Pass Pass Pass Pass 49 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Logitec LHD-HBS250SAU2 Pass Pass Pass Pass 51 Logitec LHD-HBS250U2 Pass Pass Pass Pass 52 Logitec LHD-HBS300FU2 Pass Pass Pass Pass 53 Logitec LHD-HBS300SAU2 Pass Pass Pass Pass								
46 Logitec LHD-HB750FU2 Pass Pass Pass Pass 47 Logitec LHD-HB750U2 Pass Pass Pass Pass 48 Logitec LHD-HBS1000U2 Pass Pass Pass Pass 49 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Logitec LHD-HBS250SAU2 Pass Pass Pass Pass 51 Logitec LHD-HBS250U2 Pass Pass Pass Pass 52 Logitec LHD-HBS300FU2 Pass Pass Pass Pass 53 Logitec LHD-HBS300SAU2 Pass Pass Pass Pass								
47 Logitec LHD-HB750U2 Pass Pass Pass Pass 48 Logitec LHD-HBS1000U2 Pass Pass Pass Pass 49 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Logitec LHD-HBS250SAU2 Pass Pass Pass Pass 51 Logitec LHD-HBS250U2 Pass Pass Pass Pass 52 Logitec LHD-HBS300FU2 Pass Pass Pass Pass 53 Logitec LHD-HBS300SAU2 Pass Pass Pass Pass								
48 Logitec LHD-HBS1000U2 Pass Pass Pass Pass 49 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Logitec LHD-HBS250SAU2 Pass Pass Pass Pass 51 Logitec LHD-HBS250U2 Pass Pass Pass Pass 52 Logitec LHD-HBS300FU2 Pass Pass Pass Pass 53 Logitec LHD-HBS300SAU2 Pass Pass Pass Pass								
49 Logitec LHD-HBS250FU2 Pass Pass Pass Pass 50 Logitec LHD-HBS250SAU2 Pass Pass Pass Pass 51 Logitec LHD-HBS250U2 Pass Pass Pass Pass 52 Logitec LHD-HBS300FU2 Pass Pass Pass Pass 53 Logitec LHD-HBS300SAU2 Pass Pass Pass Pass								
50 Logitec LHD-HBS250SAU2 Pass Pass Pass 51 Logitec LHD-HBS250U2 Pass Pass Pass 52 Logitec LHD-HBS300FU2 Pass Pass Pass 53 Logitec LHD-HBS300SAU2 Pass Pass Pass								
51 Logitec LHD-HBS250U2 Pass Pass Pass 52 Logitec LHD-HBS300FU2 Pass Pass Pass 53 Logitec LHD-HBS300SAU2 Pass Pass Pass								
52 Logitec LHD-HBS300FU2 Pass Pass Pass 53 Logitec LHD-HBS300SAU2 Pass Pass Pass								
53 Logitec LHD-HBS300SAU2 Pass Pass Pass Pass Pass			LHD-HBS300FU2					
55 Logitec LHD-HBS320FU2 Pass Pass Pass Pass								
56 Logitec LHD-HBS320SAU2 Pass Pass Pass Pass								
57 Logitec LHD-HBS320U2 Pass Pass Pass Pass								

58	Logitec	LHD-HBS400FU2	Pass	Pass	Pass	Pass
	Logitec	LHD-HBS400SAU2	Pass	Pass	Pass	Pass
	Logitec	LHD-HBS400U2	Pass	Pass	Pass	Pass
	Logitec	LHD-HBS500FU2	Pass	Pass	Pass	Pass
	Logitec	LHD-HBS500SAU2	Pass	Pass	Pass	Pass
	Logitec	LHD-HBS500U2	Pass	Pass	Pass	Pass
	Logitec	LHD-HBS640U2	Pass	Pass	Pass	Pass
	Logitec	LHD-HBS750FU2	Pass	Pass	Pass	Pass
	Logitec	LHD-HBS750SAU2	Pass	Pass	Pass	Pass
	Logitec	LHD-HBS750U2	Pass	Pass	Pass	Pass
	Logitec	LHD-PBE120U2BK	Pass	Pass	Pass	Pass
	Logitec	LHD-PBE120U2SV	Pass	Pass	Pass	Pass
	Logitec	LHD-PBE120U2WH	Pass	Pass	Pass	Pass
	Logitec	LHD-PBE160U2BK	Pass	Pass	Pass	Pass
	Logitec	LHD-PBE160U2SV	Pass	Pass	Pass	Pass
	Logitec	LHD-PBE160U2WH	Pass	Pass	Pass	Pass
74	Logitec	LHD-PBE40U2BK	Pass	Pass	Pass	Pass
		LHD-PBE40U2SV	Pass	Pass	Pass	Pass
	Logitec					
	Logitec	LHD-PBE40U2WH	Pass Pass	Pass Pass	Pass Pass	Pass Pass
	Logitec	LHD-PBE80U2BK				
	Logitec	LHD-PBE80U2SV	Pass	Pass	Pass	Pass
80	Logitec Logitec	LHD-PBE80U2WH	Pass	Pass	Pass	Pass
		LHD-PBF120FU2SV	Pass	Pass	Pass	Pass
	Logitec	LHD-PBF160FU2SV	Pass	Pass	Pass	Pass
	Logitec	LHD-PBF250FU2SV	Pass	Pass	Pass	Pass
	Logitec	LHD-PBF320FU2SV	Pass	Pass	Pass	Pass
	Logitec	LHD-PHA120FU2	Pass	Pass	Pass	Pass
	Logitec	LHD-PHA120U2	Pass	Pass	Pass	Pass
	Logitec	LHD-PHA160FU2	Pass	Pass	Pass	Pass
	Logitec	LHD-PHA160U2	Pass	Pass	Pass	Pass
	Logitec	LHD-PHA80FU2	Pass	Pass	Pass	Pass
	Logitec	LHD-PHA80U2	Pass	Pass	Pass	Pass
	Logitec	LHD-PS80U2WH	Pass	Pass	Pass	Pass
	Logitec	LHD-PSA120U2SV	Pass	Pass	Pass	Pass
	Mastor	Master Basics External Hard Drive (250G)	Pass	Pass	Pass	Pass
	Mastor	Mastor Basics External Hard Drive (500G)	Pass Pass	Pass Pass	Pass	Pass
_	Mobile Disk	HD-338-U2C			-	-
	NetDisk	NDAS ND10	Pass	Pass	-	-
	NuSLIM	PL-2506	Pass	Pass	- D	- Dans
	Philips	Mobile Storage Drive (300G)	Pass	Pass	Pass	Pass
	Philips	USB 2.0 Mobile Disk(SPD5220CC/96S)	Pass	Pass	Pass	Pass
	Prolific	Prolific Technology ING (160G)	Pass	Pass	Pass	Pass
100		RDC2882	Pass	Pass	- D	- Dane
	Sunplus	USB to Serial-ATA Bridge	Pass	Pass	Pass	Pass
	Teac	HD-231	Pass	Pass	-	-
	Transcend	2.5" HDD	Pass	Pass	Pass	Pass
	Transcend	StoreJet 2.5" 120G HDD	Pass	Pass	Pass	Pass
	Transcend	StoreJet 25C 320GB	Pass	Pass	Pass	Pass
	Transcend	StoreJet TS30GSJ18 30GB USB HDD	Pass	Pass	Pass	Pass
107	Transcend	StoreJet TS40GSJ25B USB HDD	Pass	Pass	Pass	Pass

108	Vantec	Nexstar.3 External 3.5" Hard Drive Enclosure	Pass	Pass	Pass	Pass			
109		USB to IDE Bridge	Pass	Pass	Pass	Pass			
	Vipower	VPA-25289	Pass	Pass	-	-			
	Xander	X-Note 2.5" 160G SATA Mobile Disk(Black)	Pass	Pass	Pass	Pass			
	Zynet	HD-D4-U2SA	Pass	Pass	Pass	Pass			
	Zynet	HD-D5-U2FW	Pass	Pass	Pass	Pass			
	Card Reader								
114	Alcor	Single Slot SD/MMC/SD-HC Card Reader	Pass	Pass	Pass	Pass			
	Elecom	MR-A10BK	Pass	Pass	Pass	Pass			
	Elecom	MR-A10GN	Pass	Pass	Pass	Pass			
	Elecom	MR-A10GY	Pass	Pass	Pass	Pass			
	Elecom	MR-A10WH	Pass	Pass	Pass	Pass			
	Elecom	MR-A11HWH	Pass	Pass	Pass	Pass			
	Elecom	MR-A13HSV	Pass	Pass	Pass	Pass			
	Elecom	MR-A14HBK	Pass	Pass	Pass	Pass			
	Elecom	MR-A14HBU	Pass	Pass	Pass	Pass			
	Elecom	MR-A14HSV	Pass	Pass	Pass	Pass			
	Elecom	MR-A14HWH	Pass	Pass	Pass	Pass			
	Elecom	MR-A20HBK	Pass	Pass	Pass	Pass			
	Elecom	MR-A20HBU	Pass	Pass	Pass	Pass			
	Elecom	MR-A20HRD	Pass	Pass	Pass	Pass			
	Elecom	MR-A20HSV	Pass	Pass	Pass	Pass			
	Elecom	MR-A20HWH	Pass	Pass	Pass	Pass			
	Elecom	MR-A33HBK	Pass	Pass	Pass	Pass			
	Elecom	MR-A33HSV	Pass	Pass	Pass	Pass			
	Elecom	MR-A33HWH	Pass	Pass	Pass	Pass			
	Elecom	MR-A47HBK	Pass	Pass	Pass	Pass			
	Elecom	MR-A47HSV	Pass	Pass	Pass	Pass			
	Elecom	MR-A47HWH	Pass	Pass	Pass	Pass			
	Elecom	MR-C10BK	Pass	Pass	Pass	Pass			
	Elecom	MR-C10SV	Pass	Pass	Pass	Pass			
	Elecom	MR-C10WH	Pass	Pass	Pass	Pass			
	Elecom	MR-C11BK	Pass	Pass	Pass	Pass			
	Elecom	MR-C11RD	Pass	Pass	Pass	Pass			
	Elecom	MR-C11SV	Pass	Pass	Pass	Pass			
	Elecom	MR-C11WH	Pass	Pass	Pass	Pass			
	Elecom	MR-C12BK	Pass	Pass	Pass	Pass			
	Elecom	MR-C12BU	Pass	Pass	Pass	Pass			
	Elecom	MR-C12BD	Pass	Pass	Pass	Pass			
	Elecom	MR-C12WH	Pass	Pass	Pass	Pass			
	Elecom	MR-C13BK	Pass	Pass	Pass	Pass			
	Elecom	MR-C13WH	Pass	Pass	Pass	Pass			
	Elecom	MR-SMC01BK	Pass	Pass	Pass	Pass			
	Elecom	MR-SSD01BK	Pass	Pass	Pass	Pass			
	E-Sense	SCR200	Pass	Pass	Pass	Pass			
	Galileo	23-in-1 Card Reader	Pass	Pass	- Fass	-			
	Genesys	SD Cad Reader Genesys Logic	Pass	Pass	Pass	Pass			
	Moai	SDMMC M121	Pass	Pass	Pass	Pass			
	Myson Century	CF Card Reader USB2.0	Pass	Pass	Pass	Pass			
	No Brand	6 in 1 Card Reader (CR-V1102-U26)	Pass	Pass	Pass	Pass			
100	ואט טומוע	U III I Calu Neauel (CR-V I 102-020)	газэ	газэ	1-000	1 000			

157	No Brand	Media Reader USB 2.0	Pass	Pass	Pass	Pass
	Philips	SD/Mini SD/MMC Card Reader	Pass	Pass	Pass	Pass
	Samsung	TRUTION TUH-7000X	Pass	Pass	-	-
	SanDisk	SDDR-113	Pass	Pass	Pass	Pass
	Sanwa	ADR-MLT1W	Pass	Pass	Pass	Pass
	SMSC	USB to Flash Device	Pass	Pass	Pass	Pass
	SUNZone	SUZCR920	Pass	Pass	N/A	N/A
	Teac	US-4SM-B	Pass	Pass	-	-
	Transcend	TS-RD13B, 13-in-1 Card Reader	Pass	Pass	-	-
166		USB2.0 Card Reader	Pass	Pass	Pass	Pass
100	VIV	VCD / D		1 400	1 400	1 433
167	Benq	DVD-RW (EW-1621)	Pass	Pass	Pass	Pass
168	Beng	DVD-RW (EW-164B)	Pass	Pass	Pass	Pass
	Buffalo	DVD Writer (DVSM-XL1218U2)	Pass	Pass	Pass	Pass
	IO Data	DVR-UEM16CR	Pass	Pass	-	-
	Logitec	LDR-MA18U2	Pass	Pass	-	-
	Logitec	LDR-PMD8U2	Pass	Pass	Pass	Pass
	Pioneer	Pioneer MULTI Recorder	Pass	Pass	Pass	Pass
	Sony	DRX-100UL	Pass	Pass	-	-
17-7	Cony	MF		1 400		
175	Apia	APIA MP3 Player	Pass	Pass	Pass	Pass
176	Apple	iPod 30G	Pass	Pass	Pass	Pass
	Apple	iPod Mini	Pass	Pass	-	-
178	Apple	iPod Video	Pass	Pass	Pass	Pass
179	Apple	iPod shuffle	-	-	-	-
180	Apple	iPod nano	-	_	-	-
181	Apple	iPod classic	-	-	-	-
182	Apple	iPod touch	-	-	-	-
183	Apple	iPhone 2G	-	-	-	-
184	Apple	iPhone 3G	-	-	-	-
	Greative	MuVO TX FM	Pass	Pass	Pass	Pass
186	Isito	IS-901B	Pass	Pass	Pass	Pass
	MP4 digtial player	F630	Pass	Pass	Pass	Pass
188	Mpio	FG100	Pass	Pass	Pass	Pass
189	Samsung	YP-E3 MP3 Player	Pass	Pass	Pass	Pass
190	Sony	NW-A806	Pass	Pass	Pass	Pass
191	Sony	NWD-B103F	Pass	Pass	Pass	Pass
		NW-E013	Pass	Pass	Pass	Pass
193	Sony	NWZ-S615F	Pass	Pass	Pass	Pass
		Flash	Drive			
	Adata	MyFlash USB2.0 1GB	Pass	Pass	-	-
	Adata	MyFlash USB2.0 512MB RB15	Pass	Pass	-	-
	Apacer	Handy	Pass	Pass	Pass	Pass
197	Buffalo	RUF2-S512-BK	Pass	Pass	-	-
	Elecom	USB Flash 128MB	Pass	Pass	-	-
	IO Data	ToteBag TB-BH512/B	Pass	Pass	-	-
	Kingston	DataTraveler 1GB	Pass	Pass	Pass	Pass
	Kingston	DataTraveler 2.0 1GB	Pass	Pass	Pass	Pass
	Lexar	FireFly (JDFF512-431)	Pass	Pass	-	-
203	PNY	PNY Attache 2.0	Pass	Pass	Pass	Pass

204	Pqi	Flash Disk 1G	Pass	Pass	Pass	Pass	
205	SanDisk	Cruzer Contour 4G	Pass	Pass	Pass	Pass	
206	SanDisk	Cruzer Contour 8G	Pass	Pass	Pass	Pass	
207	SanDisk	Cruzer Micro 1G	Pass	Pass	Pass	Pass	
208	SanDisk	Cruzer Micro 4G	Pass	Pass	Pass	Pass	
209	SanDisk	Cruzer Mini 128M	Pass	Pass	Pass	Pass	
210	Slicon Power	Touch Series USB Flash Drive 1G	Pass	Pass	Pass	Pass	
211	Sony	POCKETBIT USM512J	Pass	Pass	-	-	
	Sony	USM2GJ	Pass	Pass	Pass	Pass	
213	Sony	USM4GJX	Pass	Pass	Pass	Pass	
214	TD Star	TD Star USB Drive	Pass	Pass	Pass	Pass	
215	Transcend	JetFlash 1GB	Pass	Pass	Pass	Pass	
	Transcend	JetFlash 512MB	Pass	Pass	Pass	Pass	
217	Transcend	JF130 1GB	Pass	Pass	Pass	Pass	
	Transcend	JF168 1GB	Pass	Pass	Pass	Pass	
219	Transcend	JFV30 1GB	Pass	Pass	Pass	Pass	
		Floppy	y Disk				
220	Acer	YD-8U10	Pass	Pass	Pass	Pass	
	Mitsumi	D343GUE	Pass	Pass	Pass	Pass	
222	Mitsumi	D353FUE	Pass	Pass	Pass	Pass	
223	Mitsumi	USB FDD	Pass	Pass	Pass	Pass	
		USB 2	.0 Hub				
224	Adaptec	Hi-Speed 4 Ports USB HUB	Pass	Pass	Pass	Pass	
225	GoodTek	GH-201 USB 2.0 4 Ports Hub	Pass	Pass	Pass	Pass	
226	Hewlett-Packard	DG954A 4 Port USB2.0 HUB	Pass	Pass	-	-	
227	I-Rocks	IR-4370 Hub	Pass	Pass	Pass	Pass	
228	KINYO	HUB-3 Pro2007314211459	Pass	Pass	Pass	Pass	
229	No Brand	Mini 4 Ports Hub BP-07000153	Pass	Pass	Pass	Pass	
230	Nstyle	Chip: Genesys Logic Inc	Pass	Pass	Pass	Pass	
231	Samsung	Pleomax PUH-7000X	Pass	Pass	Pass	Pass	
		Oth	ers		<u> </u>		
232	DigiMateIII	INSTEP EX-SRIVE	Pass	Pass	Pass	Pass	Photo Bank
233	MagicPixel	MP612B	Pass*1	Pass*1	Pass*1	Pass*1	Photo Frame
234	Sony	PSP	Pass	Pass	Pass	Pass	PlayStation Portable

- : Not Tested (Only a certain function of this device was tested)

NS: This function is not supported.

Remark:

Pass*1: USB device signal issue, only at full speed.

** Devices compatibility should be the same on both Windows VISTA and Windows 7, except for the case that the device does NOT support the OS.

USE	USB Audio / USB Phone / USB Display / USB Webcam						
No	Brand	Model Name	Windows XP	Windows Vista / Windows 7**			
	USB Audio						
1	3D Sound	PU552	Pass	Pass			
2	3D Sound	USB 2.0 3D Audio Sound Card Adapter Virtual 5.1 SC18	Pass	Pass			
3	Creative	Labs Sound Blaster Digital Music SX	Pass	Pass			

4	ESMT	USB Speaker USB-269A	Pass	Pass
5	Genius	USB Audio Device	Pass	Pass
6	Hewlett-Packard	Multi-media Speakers	Pass	Pass
7	Intopic	Jazz USB Headphone Set	Pass	Pass
8	JS	USB Speaker J-6502	Pass	Pass
9	Kuro	USB Speaker KUP 700	Pass	Pass
10	Lemel	USB Speaker	Pass	Pass
	Logitec	LRT-FMAM100U	Pass	Pass
	Logitech	V20 Notebook Speakers	Pass	Pass
	Mediatek	C-Media USB Headphone Set	Pass	Pass
	Samsung	USB-335E	Pass	Pass
15		TI USB Audio DAC	Pass	Pass
	Turtle Beach	Audio Advantage Micro	Pass	Pass
10	Turtic Deach	USB Phone	1 455	1 400
17	Aipotek	VP-0002	Pass	Pass
	Corega	Advanced USB Phone CG-USBPH02	Pass	Pass
	Ipevo	CDPU-04IP	Pass	Pass
10	прето	USB Display	1 455	1 400
20	Asus	UF735	Pass	Pass
	DisplayLink	DL-1x0 Series	Pass	Pass
	DisplayLink	DL-1x5 Series ***	Pass	Pass
	Neonplus	USB2.0 VGA Adapter	Pass	Pass
	No Brand	UVT100	Pass	Pass
	140 Blalla	USB WebCam	1 455	1 400
25	Andymay	CD-06 (USB 2.0)	Pass	Pass
	Andymay	CD-07 (USB 1.1)	Pass	Pass
	Creative	Live!Cam Video IM Skype Edition (USB 1.1)	Pass	Pass
	Elecom	UCAM-DLM130	Pass	Pass
	Elecom	UCAM-DLM130HPN	Pass	Pass
	Elecom	UCAM-DLM130HSV	Pass	Pass
	Elecom	UCAM-DLM130HWH	Pass	Pass
	Elecom	UCAM-DLQ30	Pass	Pass
	Elecom	UCAM-DLS30HBK	Pass	Pass
	Elecom	UCAM-DLS30HPN	Pass	Pass
	Elecom	UCAM-DLS30HSV	Pass	Pass
	Elecom	UCAM-E130HBU	Pass	Pass
	Elecom	UCAM-E130HSV	Pass	Pass
	Elecom	UCAM-E130HWH	Pass	Pass
	Elecom	UCAM-E130HWH	Pass	Pass
	Empia	JHY107	Pass	Pass
41	Gdmall	Cyber Cam Max (USB 1.1)	Pass	Pass
42	Intopic	Web Live620-W (USB 2.0)	Pass	N/A
43	Intopic	Web Live660-G (USB 1.1)	Pass	Pass
	Ipevo	Ipevo POV CDVU-02IP	Pass	Pass
	Kinyo	My EZCam PCM-531 (USB 1.1)	Pass	Pass
46	Logitech	QuickCam Chat(快看分享版)	Pass	Pass
47	Logitech	QuickCam Chat(快看聊天室) (USB 1.1)	Pass	N/A
	Logitech	QuickCam Communication STX	Pass	Pass
	Logitech	QuickCam Pro 3000	Pass	N/A
		ICHUNCAULETU JUUU	Fass	IN/A

50	Microsoft	LifeCam VX-3000 (USB 1.1)	Pass	Pass
51	Microsoft	LifeCam VX-7000 (USB 2.0)	Pass	Pass
52	Nstyle	NWC-532 (USB 2.0)	Pass	Pass
53	ORITE	MB-630 (USB 1.1)	Pass	N/A
54	Philips	Webcam SPC500NC (USB 1.1)	Pass	Pass
55	Ronald	Digital Camera L-1 (PC222) (USB 2.0)	Pass	Pass
56	T.C.Star	TCB-P262 (USB 2.0)	Pass	Pass
57	T.C.Star	TCB-A322 (USB 2.0)	Pass	Pass
58	TASCORP	JPEG USB Video Camera (USB 1.1)	Pass	N/A
59	V-Gear	TalkCam Live AMVG1-010-063-02-G (USB 1.1)	Pass	Pass

- : Not Tested (Only a certain function of this device was tested)

NS: This function is not supported.

** Devices compatibility should be the same on both Windows VISTA and Windows 7, except for the case that the device does NOT support the OS.
*** DL-195 requires Gigabity bandwidth and does NOT work on 100 Mbps network connection.

Μοι	Mouse / Keyboard / Joystick						
No	Brand	Model Name	Windows XP	Windows Vista / Windows 7**			
		Mouse					
1	Acer	GM-03024A	Pass	Pass			
2	Acer	NB Mouse	Pass	Pass			
3	DELL	M056U0	Pass	Pass			
4	Detrois	PS/2 + USB Mouse	Pass	Pass			
5	HP	M-UAE96	Pass	Pass			
6	HP	M-UV94	Pass	Pass			
7	IBM	USB Device 04B3	Pass	Pass			
8	Lemel	M857C	Pass	Pass			
9	Logitech	M-BB48	Pass	Pass			
10	Logitech	M-BD53	Pass	Pass			
11	Logitech	MX310	Pass	Pass			
12	Logitech	USB Mouse M-UAG120	Pass	Pass			
13	Logitech	USB Mouse M-UV94	Pass	Pass			
14	Logitech	USB Optical Mouse	Pass	Pass			
15	Microsoft	Compact Optical Mouse M-000008	Pass	Pass			
16	Microsoft	Wheel Mouse Optical USB and PS/2 Compatible X08-71118	Pass	Pass			
17	Microsoft	X800898	Pass	Pass			
18	Samsong	Acrox USB & PS/2 Mouse	Pass	Pass			
19	Samsong	Pleomax PS/2+ USB Mouse	Pass	Pass			
		Keyboard					
	BTC	8113W	Pass	Pass			
21	BTC	8193C	Pass	Pass			
22	Hewlett-Packard	KU-0316	Pass	Pass			
23	Intopic	KDB-USB-10W	Pass	-			
24	No Brand	PS/2 Mouse & Keyboard Connertor to USB	Pass	Pass			
		Joystick					

25	DragonRise	Generic USB Joystick	Pass	Pass
26	Genesys	Genesys Logic	Pass	-
27	Logitech	Driving Force EX	Pass	Pass
28	Logitech	RumblePad 2 G-UF13	Pass	Pass
29	Logitech	WingMan Formula Force GP	Pass	Pass
30	Logitech	Wingman Strike Force 3D	Pass	Pass

- : Not Tested (Only a certain function of this device was tested)

NS: This function is not supported.

^{**} Devices compatibility should be the same on both Windows VISTA and Windows 7, except for the case that the device does NOT support the OS.

	Support WebCam				
No	Brand	Model Name			
1	Microsoft	LifeCam Cinema			
2		LifeCam VX-800			
3		LifeCamVX-5500			
4		LifeCamVX-2000			
5		Webcam C120			
6	.Logitech	Webcam C200			
7		QuickCam Pro for Notebooks			
8		Webcam C300			